

DIMENSIONING

There are several dimensioning methods shown below.

The first method is my preferred way for the dimensioning wood walls (above grade).

The second method is best for masonry (foundation) where you dimension from edge to edge. Interior walls in residential are usually wood so you would want to dimension them as in method 1.

The third method includes walls that meet the exterior wall on the outside. Interior walls that do not still need to be dimensioned on the inside.

The fourth method is a basic method used for the homeowner or as a presentation drawing. One could not build the house from that.

