

# SWITCHES

NAME	ABBREV	SYMBOL	ELEVATION	PICTORIAL
SWITCH SINGLE-POLE	S	OR — + S		
SWITCH DOUBLE-POLE	S <sub>2</sub>	— + S <sub>2</sub>		
SWITCH THREE-WAY	S <sub>3</sub>	— + S <sub>3</sub>		
SWITCH FOUR-WAY	S <sub>4</sub>	— + S <sub>4</sub>		
SWITCH WEATHERPROOF	S <sub>WP</sub>	— + S <sub>WP</sub>		
SWITCH AUTOMATIC DOOR	S <sub>D</sub>			
SWITCH PILOT LIGHT	S <sub>P</sub>	— + S <sub>P</sub>		
SWITCH LOW-VOLTAGE SYSTEM	S	— + S		
SWITCH LOW-VOLTAGE MASTER	MS	— + MS		
TWO SWITCHES	SS	— + S S		
THREE SWITCHES	SSS	— + S S S		
TELEVISION AERIAL OUTLET	TV AER	— + TV		
DUPLEX OUTLET	DUP OUT	— +		
SINGLE OUTLET	S OUT	— +		

continued

NAME	ABBREV	SYMBOL	ELEVATION	PICTORIAL
CLOCK OUTLET	CLK OUT	— +		
BUZZER	BZR	— +		
CHIME	CH	— + CH		
FIRE ALARM	FA	— +		
FAN	F	— +		
SERVICE PANEL WITH SWITCHES	SERV PN/SW	— +		
ELECTRIC HEATER	ELEC HTR	— +		
JUNCTION BOX	JUNC BX	— +		
PUSH BUTTON	PB	— +		
ELECTRIC DOOR OPENER	ELEC DR OP	— +		
INTERCOMMUNICATION	INTER-COM	— +		
TELEPHONE OUTLET	TEL OUT	— +		
TELEPHONE JACK	TEL JK	— +		
DIMMER SWITCH	DM SW	— + S <sub>DM</sub>		

# OUTLETS

NAME	ABBREV	SYMBOL	ELEVATION	PICTORIAL
TRIPLE OUTLET	TR OUT			
WEATHERPROOF OUTLET	WP OUT			
SPLIT WIRE OUTLET	SPT WR OUT			
FLOOR OUTLET	FL OUT			
OUTLET WITH SWITCH	OUT/S			
HEAVY-DUTY OUTLET 220 VOLTAGE	HVY DTY OUT			
SPECIAL-PURPOSE OUTLET 110 VOLTAGE	SP PUR OUT			
RANGE OUTLET	R OUT			
REFRIGERATOR OUTLET	REF OUT			
WATER HEATER OUTLET	WH OUT			
GARBAGE-DISPOSAL OUTLET	GD OUT			
DISHWASHER OUTLET	DW OUT			
WASHER OUTLET	W OUT			
DRYER OUTLET	D OUT			

NAME	ABBREV	SYMBOL	ELEVATION	PICTORIAL
MOTOR OUTLET	M OUT			
STRIP OUTLET	STP OUT			
GROUNDED OUTLET	GRD OUT			
LIGHTING OUTLET-CEILING	LT OUT CLG			
LIGHTING OUTLET-RECESSED	LT OUT REC			
LIGHTING OUTLET-WALL	LT OUT WALL			
LIGHTING OUTLET-CEILING PULL SWITCH	PS			
FLOOD LIGHT	FL			
SPOT LIGHT	SL			
LIGHTING OUTLET-VAPOR PROOF	VP			
WALL BRACKET LIGHT WITH SWITCH	WL BRK LT/S			
LIGHTING FLUORESCENT	LT. FLUOR			
EXIT LIGHT	EXT LT			
ILLUMINATED HOUSE NUMBER	ILL HSE NO			